

Red Snapper 4 Knob User Guide

Power: 9v battery or power supply not to exceed 200ma

Battery access is through bottom plate

Power Adapter: Positive ring/negative center when using a battery, unplug the input when not in use to extend battery life.

Menatone only recommends Voodoo Labs power supplies. Use others at your own risk.

Controls:

Gain: adjusts the level of distortion

Vol: if I have to explain this you have larger problems than this pedal can fix.

Bite: this controls the level of distortion in the “pick attack” frequencies.

Cut: turn up to cut high frequencies

As with all Menatone products there are no right or wrong settings. Play around with the controls to find your own tone.